BEFORE-USE INSPECTION: HARNESS AND LANYARD

NAME OF THE WEARER

HARNESS MODEL AND SERIAL NUMBER

LANYARD / SRL MODEL AND SERIAL NUMBER

JOB SITE

OK = in good condition and working · **Fix** = damaged, missing or not working · **N/A** = not on this machine

1. Labels	OK	Fix	N/A
Label is on the harness and readable (maker, model, date of manufacture)	◯	◯	◯
Label is on the lanyard or SRL and readable	◯	◯	◯
Inspection record or tag is current, per the manufacturer	◯	◯	◯

2. Harness webbing and stitching	OK	Fix	N/A
No cuts, tears, fraying or broken fibers	◯	◯	◯
No burns, melted spots, paint or chemical damage	◯	◯	◯
No hard, stiff or faded webbing	◯	◯	◯
Stitching is intact: no pulled, cut or broken threads	◯	◯	◯
Fall indicator on the harness is not deployed (where fitted)	◯	◯	◯

3. Harness hardware	OK	Fix	N/A
Back D-ring: no cracks, bends, sharp edges or corrosion	◯	◯	◯
Buckles and adjusters work and hold	◯	◯	◯
Grommets and keepers are in place	◯	◯	◯

4. Lanyard or self-retracting lifeline	OK	Fix	N/A
Shock absorber pack is not opened or deployed	◯	◯	◯
Lanyard webbing or rope: no cuts, fraying or burns	◯	◯	◯
Snap hooks and carabiners close and lock by themselves	◯	◯	◯
SRL pulls out smoothly, retracts and locks when jerked (where used)	◯	◯	◯
Lanyard length is right for the basket (no slack to climb over the rails)	◯	◯	◯

5. Fit	OK	Fix	N/A
Right size; chest and leg straps snug, a flat hand fits under them	◯	◯	◯
Back D-ring sits between the shoulder blades	◯	◯	◯
Lanyard is attached to the basket anchor point, not to a guardrail	◯	◯	◯

◯ **OK to use** ◯ **Removed from service and tagged**

NOTES AND DEFECTS FOUND

SIGNATURE

DATE AND TIME

This checklist does not replace the manufacturer's operator manual for your machine. Follow the manual's inspection list and limits where they differ.